



CA 100

COMPRESSED AIR SYSTEM



Bedienungsanleitung
Operating manual
Mode d'emploi
Instruktionsbok

Seriennummer
Serial number
Numéro de série
Serienr.



Introduction

With the RWS CA 100 Compressed Air System, you have opted for a new concept in an environmental-friendly air rifle. This air rifle has been produced for Dynamit Nobel by a reputable English manufacturer.

As the maker of the world-famous RWS Air Rifle Pellets, Dynamit Nobel is equally skilled in the area of producing rifles for the sport of target airgun shooting. Dynamit Nobel is invariably represented at every major national and international sporting event.

Before firing your CA 100 for the first time, make sure you are familiar with the handling and special functions of the rifle. Please read the operating manual carefully.

Incorrect handling, changes to the rifle, self-inflicted damage, repairs carried out by third parties will exempt the manufacturer/Dynamit Nobel from all warranty claims. We recommend that from time to time you have your air rifle tested for safety through a recognised service centre.

Condition on delivery/packaging

The RWS CA 100 Compressed Air System leaves the production plant in a safe polystyrene packaging including cardbox. Depending on the choice you have made, sights will either be included or not.

For reasons of safety the compressed air cylinder has not been filled by the manufacturer.

- 1 DIN-fitting for connecting the rifle cylinder/compressed air bottle
- 1 spanner for the interchangeable cylinder
- 1 socket wrench set
- 1 spare barrel seal (O-ring)
- 1 spare regulator seal (O-ring)
- 1 operating manual
- 1 warranty card
- 1 RWS championship box of R 10 air rifle pellets

Technical data

| | |
|----------------------|---------------------------------|
| Calibre | 4,5 mm (.177) |
| Barrel length | 558 mm |
| Total length | 112 cm |
| Weight (with sights) | 5,18 kg |
| Filling pressure | 200 bar, maximum |
| Propulsion energy | dry and oil-free compressed air |
| Firing capacity | maximum 250 shots |

Garantie

Für das RWS-Luftgewehr CA 100 übernimmt die Dynamit Nobel AG folgende Garantie:

Die Dynamit Nobel AG garantiert Ihnen als Käufer für diejenigen Teile, die infolge von Material- oder Herstellungsfehlern schadhaft geworden sind, kostenlose Reparatur oder kostenlosen Ersatz während der Dauer von einem Jahr, gerechnet ab dem Datum der Garantieurkunde.

Die Garantie erstreckt sich nicht auf Beschädigungen oder Störungen, die infolge unsachgemäßer Behandlung oder Eingriffen, infolge schlechter Instandhaltung oder durch natürliche Abnutzung oder Verschleiß verursacht worden sind. Die Garantie gewährt keine Schadenersatzansprüche und faßt keine Nebenkosten, das heißt, die durch die Ein- oder Rücksendung des Gewehres oder schadhafter Teile entstehenden Fracht-, Porto-, Versicherungs- und Zollkosten gehen zu Lasten des Käufers.

Die Anmeldung von Garantieansprüchen soll grundsätzlich über den Fachhandel beziehungsweise den Importeur erfolgen. Für die Ausführung von Garantiearbeiten sind nur die Dynamit Nobel AG und von dieser autorisierte Werkstätten zuständig.

Warranty

Dynamit Nobel issues the following warranty for the RWS CA 100.

Under the Warranty, Dynamit Nobel AG undertakes to repair or replace free of charge all parts which are faulty due to defective material or manufacture for the period of a year from the date of receipt of the warranty certificate.

The warranty does not cover damage or malfunction attributable improper treatment, poor maintenance or normal wear and tear. The warranty does not include claims for damages and does not extend to secondary costs, i.e. the costs of freight, postage, insurance and duty incurred in sending and returning the gun or damaged parts shall be charged to the purchaser.

Warranty claims should always be lodged with your dealer or importer. Warranty work may only be carried out by Dynamit Nobel AG and workshops authorized by Dynamit Nobel AG.

Garantie

La Société Dynamit Nobel AG accorde la garantie suivante sur son arme à air CA 100.

Pour toutes les pièces devenues défectueuses à la suite de défauts de matériaux ou de fabrication, Dynamit Nobel AG s'engage, envers l'acheteur, à réparer ou à remplacer gratuitement les dites pièces pour une période d'un an à compter de la date du certificat de garantie.

La garantie ne couvre pas les dommages ou les anomalies résultant d'une manipulation ou d'interventions inadéquates, d'une réparation mal effectuée ou de l'usure naturelle de l'arme. La garantie ne reconnaît aucun droit à réparation de préjudices et ne couvre pas les coûts accessoires, c'est-à-dire que les frais de transport, d'affranchissement, d'assurance et de dédouanement pour l'envoi et le renvoi de l'arme ou des pièces défectueuses sont à la charge de l'acheteur.

Les prétentions de garantie doivent exclusivement être transmises par le commerce spécialisé ou par l'importeur. Seuls la Dynamit Nobel AG et les ateliers autorisés par celle-ci sont compétents pour l'exécution des travaux relevant de la garantie.

Garanti

Dynamit Nobel lämnar följande garanti på RWS CA 100.

Dynamit Nobel ersätter trasiga delar och fel beroende på tillverkaren. Denna garanti gäller under en tid av ett (1) år från försäljningen.

Garantin täcker inte skador eller funktionsproblem som beror på felaktigt handhavande eller dålig vård av vapnet. Normala förslitningsskador ersätts inte. Garantin täcker inte extrakostnader såsom frakt, postavgifter, försäkringar och tull. Kostnader för tur- och retursändning av vapnet eller skadade delar ombesörjs av köparen.

Garantianspråk skall alltid lämnas till den Ni köpt vapnet av eller till Dynamit Nobel-RWS, Skandinavien. Garantiarbeten får endast utföras av Dynamit Nobel eller av denne anvisad vapenreparatör.

RWS CA 100

Serien-No.:/Serial-No.:
Nr.Serie:/Serienr.:

Verkaufsdatum:/Date of purchase:
Date de vente:/Försäljningsdatum:

Händleradresse/Dealer's adress
Adresse du revendeur/Handlare-adress

Care and maintenance

The working parts of your RWS CA 100 need relatively little in the way of lubricating and cleaning. Given normal use of the air rifle, the manufacturer's lubrication is sufficient for up to 10,000 shots max. Improper care will result in this capacity being considerably reduced.

It is recommended that once a year, (or after every 10,000 shots,) the rifle is taken to an expert for an inspection and overhaul. Such a service, which can only be carried out by a recognised specialist, will ensure that all the care and maintenance measures necessary are properly undertaken.

Each time it has been used, the rifle should be wiped thoroughly with a cloth, and metal and wooden surfaces protected against corrosion by means of an appropriate oil.

We advise that the inside of the barrel should be cleaned at longer intervals by slushing it out with several dry-cleaning drops (e.g. VFG)

General safety precautions in the use of guns

Always remember that you keep a firearm. Observing the following rules can prevent accidents from occurring:

1. Always make sure when you pick up a gun that it is unloaded.
2. Only let go off your gun if it is unloaded.
3. Leave the breech block open, unless you are about to fire.
4. Never point your gun - even unloaded - at a person or in a direction where it might be dangerous or lead to injury.
5. Only fire your gun on officially recognised shooting ranges or at targets sited against an appropriately safe background.
6. Do not touch the trigger until you are on the point of firing.
7. Always keep gun and ammunition locked away separately.
8. Only hand your gun to persons of a suitably mature age who are familiar with the correct methods of handling it and with the safety rules involved in firing it.
9. Always treat your gun as if it were loaded. Make sure yourself that the gun is unloaded.

Trigger

The trigger of the RWS CA 100 Compressed Air System can be individually adjusted to meet the requirements of the shooter. The adjustment options are as follows:

Trigger weight

The trigger weight is adjusted by turning screw (1) clockwise to increase the weight, and anticlockwise to decrease the weight.

1st stage travel

1st stage travel is adjusted by means of screw (2). Turning the screw clockwise will decrease travel, anticlockwise will increase it.

Let-off point (catch overlap)


The let-off point is adjusted with screw (3). Turning the screw clockwise will make the let-off point "drier", i.e. only a slight catch overlap is set. Turning the screw too far anticlockwise will cause the rifle to fire before the end of 1st stage travel. Clockwise turning will increase the catch overlap, i.e. the trigger "travels" or is dragged.

Follow-on travel adjustment

Follow-on travel is adjusted with screw (7). Turning the screw anticlockwise will reduce the travel, while clockwise turning will extend the follow-on of the trigger once the let-off point has been passed.

The position of the trigger shoe can be set on 3 levels:

- a The height adjustment is effected by loosening screw (4) and sliding the shoe either up or down on the trigger blade.
- b The length adjustment is effected by loosening screw (6) and moving the trigger blade (B) along the trigger bar (C).
- c The angle adjustment is effected by loosening screw (5) and swinging the trigger bar (C) on the pivot block (D).



Compressed air logistics


The compressed air reservoir (B) is filled by the shooter at the relevant specialist retailer. The technical provisions and regulations in force in each state for filling the rifle with compressed air and transporting the compressed air receptacles must be complied with.

Compressed air can be obtained at the various branches of commercial suppliers or at specialised diving and sports equipment centres.

The compressed air reservoir or 3-litre refill bottle obtainable as an accessory can be topped up from large industrial cylinders (approx. 50 litres) or directly from an appropriate compressor. The DIN fitting with drain valve is required for this purpose, which is likewise obtainable as an accessory.

Cocking/loading

- A The breech block (1) is retracted by pressing down the release lever (2) on both sides.
- B The breech block (1) is pushed back fully with the index finger until it locks in. The breech system is now taut and the air pellet may be loaded into the breach.
- C The breech block (1) is now pushed forward, hermetically sealing the barrel at the back. Once the rifle has been fired, the release lever (2) is actuated and the breech block (1) returns to position A.



Discharging

Once the loading process is complete, the pellet may no longer be removed from the rear of the barrel. To interrupt the firing procedure, retract the breech block (1) by pressing the two release levers (2) simultaneously. Once released from the firing position, the breech block (1) can be pushed forward again and firing continue.

The air rifle can be discharged by firing the pellet inserted in the barrel. The necessary safety regulations must be strictly observed at all times.

Filling with compressed air

General advice regarding compressed air

In handling compressed air, it is necessary that only "dry" compressed air is used. When filling with a compressor, the system should have a water separator. It is recommended that the compressed air reservoir is never emptied completely in order to prevent condensed water from forming there. (Danger of rust!)

As a propulsion agent, only compressed air - not CO₂ - must be used. Filling the reservoir (B) with CO₂ will lead to malfunctioning and material damage. Use of CO₂ will invalidate the warranty.



Filling the rifle cylinder

Integrated into the front of the cylinder (B) is a pressure gauge (manometer). The filling pressure level can be read at any time, even during competition. One graduation mark on the scale is equivalent to 25 bar.

0 bis 50 bar : yellow (given a shortfall in operating pressure, cylinder must be refilled)

50 bis 200 bar : green (min./max. filling pressure)

über 200 bar : red (overpressure, the pressure indicator must not reach this area)



The compressed air reservoir (B) should be filled at approx. 160 bar, sufficient for 200 shots; 200 bar is maximum.

Note:

Should the level fall short of the minimal filling pressure, the rifle is not ready for firing, and a consistent point of impact can no longer be guaranteed.

It is likewise essential that the maximum filling pressure of 200 bar is not exceeded. However, given proper use of the permitted filling sources and an admission pressure of 200 bar max., exceeding the maximum pressure is a technical impossibility.


Emptying the rifle cylinder

In the threaded aperture of the cylinder there is a valve rod. This can be pushed inwards to release the compressed air.

Assembly/disassembly of the compressed air reservoir


The CA 100 is equipped with a detachable compressed air reservoir (B). By using of the spannes provided (D), this can be loosened from the air rifle between the pressure gauges (A1-A4) and the pressurised cylinder. It is then unscrewed manually and removed from the rifle towards from the front. Not requiring the use of a tool, the DIN fitting (C) is next screwed on to the reservoir. (B). Finally the entire system is connected up to either a compressor, a refill bottle or a large supply bottle. Attached to the refill bottle supplied by Dynamit Nobel is a pressure gauge that allows the contents to be read.

The reservoir (B) should be filled until the indicator registers a maximum. It is essential that attention is paid to the pressure gauges (A1-A4) during the filling process so that this may be carried out effectively. The reservoir (B) may only be shut off again once the drain valve has been closed.



By operating the air rifle release lever (2), the breech block (1) will spring back, thus allowing it to be pulled back and locked into position. The reservoir (B) is then reinserted into the rifle, under the barrel from the front, where it is screwed in manually and lightly tightened up with the original spanner (D).

The original spanner (D) is deliberately made from soft material to avoid the reservoir (B) being screwed on too tightly.



Important

Should the breech block (1) not be pulled back fully prior to refitting the reservoir (i.e. so the rifle is cocked), then compressed air will be heard to escape. The breech block (1) may be opened still further to prevent more air from escaping, but a loss of compression is to be expected.


Adjusting the cheek piece

Height adjustment

The lateral locking screw (2) is loosened and the cheek piece (B) raised to the desired position. Tighten the lateral screw (2) to secure cheek piece (B) in the desired position.

Lateral adjustment

The lateral locking screw (2) is loosened and the cheek piece (B) raised to the desired position. Through tightening the lateral locking screw (2) is loosened and the cheek piece (B) are loosened and the metal section (4) moved to the side as appropriate. Finally the screws (3) are tightened up again, the cheek piece (B) is slid back down in the stock via the guide bolts (5) and fixed in the desired position again by tightening the lateral screw (2).



Adjusting the shoulder pad

The rear locking crew (1) is loosened, the height of the shoulder pad (A) individually adjusted, and the screw (1) tightened up again.


Dioptré assembly and adjustment

The dioptré sights are attached by inserting the dovetail guide into the grooved rib of the air rifle. Once the desired optical distance has been set, the fastening screws should be carefully tightened.

The point of impact of your RWS CA 100 can be regulated by adjusting the diopter. In doing so, you should observe the corresponding markings on the adjuster screws:


- for high shots: turn upper adjuster screw towards H (right)
- for low shots: turn upper adjuster screw towards T (left)
- for shots right: turn side adjuster screw towards R (right)
- for shots left: turn side adjuster screw towards L (left)

One click/catch corresponds, at a distance of 10 m, to an approx. 0,5 mm adjustment to the point of impact. Each adjusting screw is numerically marked =-10 so that the previous setting can be located easily.



Tunnel front sight


The positioning of the adjusting bar takes place via the tunnel of the front sight. This is provided with line markings. By means of the screw located on the front, the adjusting bar is held firm at the desired angle. The rear thumbwheel is unscrewed so far by hand that the mounted front sight can be detached from the groove. The new front sight blade once inserted is then slid into the lateral recesses. The side pieces are of various widths and the front sight blade is to be inserted accordingly. Finally the thumbwheel is tightened up by hand again.




Barrel weight

Once the socket-head cap screw has been loosened, the barrel weight can be slid backwards and forwards. The weight can then be individually positioned by each shooter. By means of the socket-head cap screw, the weight can then be secured from slipping out of place.


| Teile/Part-Nr | Bezeichnung | Description | Teile/Part-Nr | Bezeichnung | Description |
|---------------|------------------------------|------------------------------|---------------|---|------------------------------|
| 101 | Gehäuse | Main Body | 325 | Abzugsträger | Trigger Bar |
| 103 | Führungsbuchse | Striker Bush | 328 | Abzugsträger-Schraube | Trigger Bar Screw |
| 105 | Abdeckplatte | Cover Plate | 330 | Abzug | Trigger Pillar |
| 106 | Schraube für Abdeckplatte | Cover Plate Screw | 331 | Abzugs-Schraube | Trigger Pillar Screw |
| 110 | Lauf | Barrel | 350 | Abzugsschuh | Trigger Shoe |
| 111 | Lauf-O-Ring 12x2mm | Barrel O Ring | 351 | Abzugsschuh-Mutter | Trigger Shoe Nut |
| 112 | Laufmantel | Barrel Tube | 352 | Abzugsschuh-Schraube | Trigger Shoe Screw |
| 113 | Mantel-Halterschraube | Tube Retaining Screw | 355 | Gehäusestift 3x20 mm | Body/sear Pin 3x20mm |
| 115 | Lauf-Halterschraube | Barrel Retaining Screw | 356 | Gehäusestift 2x20mm | Body/sear Pin 2x20mm |
| 125 | Verschlußblock,kpl. | Breech Block Assembly | 360 | Abzugsfeder | Trigger Spring |
| 128 | Verschlußblock-O-Ring | Breech Block O Ring | 365 | Abzugsfeder-Platte | Trigger Spring Plate |
| 130 | Verschlußblock-Führung | Breech Block Shaft | 370 | Einstellschraube für Abzugsgewicht | Trigger Spring Plate Screw |
| 131 | Distanzscheibe 0,10mm | Breech Block Spacer 0,10mm | 375 | Begrenzungsschraube | Adjuster Screw |
| 132 | Distanzscheibe 0,15mm | Breech Block Spacer 0,15mm | 380 | Schaftschraube (hinten) | Rear Stock Screw |
| 135 | Verschlußblock-Schraube | Breech Block Screw | 385 | Unterlegscheibe (vorne) | Stock Washer Front |
| 140 | Verschluß-Rückholfeder | Breech Return Spring | 386 | Unterlegscheibe (hinten) | Stock Washer Rear |
| 142 | Rückholfeder-Stift | Return Spring Pin | 400 | Schaftrücken-Träger (oben) | Stock Adjuster Top Plate |
| 143 | Federhalter | Spring Retainer | 405 | Schaftrücken-Träger (unten) | Stock Adjuster Bottom Plate |
| 146 | Verschlußblock-Druckbolzen | Breech Block Plunger | 410 | Träger-Bolzen | Stock Adjuster Pillar |
| 150 | Feder zu 146 | Plunger Spring | 415 | TrägerAbschlußplatte | Stock Adjuster Locking Plate |
| 155 | Schraube zu 146 | Plunger Screw | 420 | Feststellschraube | Stock Adjuster Locking Screw |
| 160 | Öffnungshebel-Führung | Breech Release Shaft | 425 | Schraubenführung | Stock Adjuster Locking Bush |
| 165 | Verschluß-Öffnungshebel | Breech Release Lever | 430 | Schraube für Träger (oben) | Top Plate Screw |
| 170 | Öffnungshebel-Stift | Release Lever Pin | 431 | Zwischenscheibe | Top Plate Washer |
| 175 | Öffnungshebel-Feder | Release Lever Spring | 435 | Schraube für 405 | Bottom Plate Screw |
| 180 | Ventilsitz | Valve Seat | 440 | Vorderschafts-Schiene | Stock Rail |
| 185 | Ventil-Schraube | Valve Seat Screw | 445 | Schienen-Schraube | Stock Rail Screws |
| 190 | Ventil-O-Ring 10x1mm | Valve Seat O Ring 10x1mm | 450 | Rechtsschaft | Rh Stock |
| 192 | Ventil-O-Ring 14x1mm | Valve Seat O Ring 14x1mm | 450A | verstellbarer Schaftrücken, rechts | Rh Adjustable Cheek Piece |
| 195 | Schließ-Ventil, kpl. | Firing Valve Assembly | 451 | Linksschaft | LH Stock |
| 198 | Schließ-Ventil-Feder | Firing Valve Spring | 451A | verstellbarer Schaftrücken, links | LH Adjustable Cheek Piece |
| 200 | Piston (Kolbenstange) | Striker | 456 | Schaftkappe | Butt Pad |
| 205 | Hauptfeder | Mainspring | 457 | Schaftkappen-Basis | Butt Pad Base |
| 210 | Hauptfeder-Regler | Mainspring Adjuster | 458 | Zwischenstück (Schaftverlängerung) | Butt Pad Spacer |
| 215 | Sicherungsstift für 210 | Adjuster Lock Pad | 460 | Schaftkappen-Schraube | Butt Pad Srews |
| 219 | Regulator kpl. | Regulator Assembly | 462 | Gewindeplatte | Butt Pad Locking Plt |
| 232 | Regulator-Körper-O-Ring | Regulator To Body O Ring | 470 | Gabelschlüssel | Spanner |
| 235 | Druckbehälter-Rohr | Cylinder | 480 | Laufgewicht, vorne (40g) | Front Barrel Weight 40g |
| 236 | Regulator-Abschluß-O-Ring | Cylinder To Regulator O Ring | 481 | Laufgewicht,vorne (105g) | Front Barrel Weight 105g |
| 241 | Manometer-Überring | Manometer Cover Ring | 485 | Laufgewicht,verstellbar (30g) | Rear Barrel Weight 30g |
| 245 | Füll-Ventil | Filling Valve | 490 | Schraube für Laufgewicht | Barrel Weight Screw |
| 250 | Manometer | Manometer | 495 | Fixierplatte für Regulator | Regulator Locking Plate |
| 251 | Manometer-Dichtung | Bonded Seal | 496 | Schraube für 495 | Regulator Locking Screw |
| 270 | Laufhalter | Bridge Clamp | 510 | Nachfüll-Adapter | Din Adaptor |
| 272 | Vorderschafts-Schraube | Front Stock Screw | 510V | Nachfüll-Adapter mit Entlüftungsschraube | Din Adaptor With Vent Screw |
| 273 | Puffer für Druckbehälter | Cylinder Bearer Pad | 511V | Entlüftungsschraube | Vent Srew |
| 275 | Spannarm | Cocking Arm | 515 | Adapter-O-Ring | Adapter O Ring - Bs111 |
| 280 | Feder für Spannarm | Top Sear Spring | 520 | Adapter-O-Ring | Adapter O Ring - Bs116 |
| 281 | Spannarm-Distanzhalter innen | Cocking Arm Spacer Inner | 540 | Ersatz-O-Ring-Set Nr.128, 236,515,520 | Spare O Rings |
| 282 | Spannarm-Distanzhalter außen | Cocking Arm Spacer Outer | 545 | Inbusschlüssel Satz | No.128, 236,515,520 |
| 284 | Abzugsklinke, kpl. | Top Sear Assembly | | | Tool Set |
| 295 | Spannarm-Feder | Cocking Arm Spring | | | |
| 300 | Mittelhebel | Middle Sear | | | |
| 305 | Mittelhebel-Block | Middle Sear Block | | | |
| 310 | Mittelhebel-Schraube | Middle Sear Screw | | | |
| 315 | Abzugs-Drehblock | Trigger Pivot Block | | | |
| 321 | Stellschraube für 315 | Pivot Block Vertical Stop | | | |
| 322 | Stellschraube für Abzugsweg | Pivot Block Horizontal Stop | | | |




RWS Mod. CA 100



DIN Adapter



DIN Adapter mit Abluftventil



NICHT-ÜBERBRÜCKEN
470

